



Item	☆	Part NO.	Description	Q'ty	Item	☆	Part NO.	Description	Q'ty	Item	☆	Part NO.	Description	Q'ty
1		106227	Screw Socket Hd	4	26		100174	Roll Pin	1	51		105612	Pin	1
2		100638	Washer	4	27		100039	Roll Pin	3	52		105717	Pin	1
3		105443	Cylinder Cap Unit	1	28		105469	Trigger Valve Unit	1	53	☆	105627	Pusher Spring	2
4	☆	105445	Seal, Cylinder Cap	1	29		105471	Compression Spring	1	54		104044	Pin	1
5		105446	Spacer, Piston Stop	1	30		105470	Valve Stem	1	55		105613	Pusher	1
6	☆	105447	Piston Stop	1	31		105856	O-Ring	1	56		105618	Steel Channel	1
7		103575	Spring	1	32		105473	Valve Body	1	57		106509	Pin	1
8	☆	105449	O-Ring	1	33		105474	Trigger Unit (CT)	1	58		105604	Magazine Core Assembly	1
9		105451	Head Valve Piston	1	34		105482	Arm Guide	1	59		100654	Lock Nut	2
10	☆	105450	O-Ring	2	35		105544	Screw Socket Hd	1	60		106858	Screw Socket Hd	2
11		105454	O-Ring	1	36		106850	Compression Spring	1	61		106400	Spring Stopper	1
12	☆	103563	Piston Ring	1	37		105594	Nose	1	62		105616	Magazine Cap	1
13	☆	105619	Main Piston Unit	1	38		105534	Step Pin	1	63		105617	Stopper	1
14		105456	Cylinder Seal	1	39		105598	Nose Guide	1	64		100687	Spring Washer	2
15		105610	Cylinder	1	40		109127	E-Retainer Ring	1	65		100778	Hex.Soc.Hd.Bolt	2
16		105458	O-Ring	1	41		106401	Lower Contact Arm	1	66		105600	Contact Arm	1
17		105459	Cylinder Ring	1	42		100933	Screw Socket Hd	2	67		100301	Screw Socket Hd M5*10	2
18		103738	O-Ring	1	43		105531	Nose Plate Lock	1	68		105608	Magazine Bracket	1
19		105460	O-Ring	1	44		105596	Cover, Contact Arm	1	69		101688	Screw Socket Hd	1
20	☆	105461	Bumper	1	45		106097	Roll Pin	1	70		105715	Screw Socket Hd	2
21	☆	105611	Driver Guide	1	46		105606	Cover, Magazine	1	71		105614	No-Mar Tip	2
22		105463	Frame	1	47		105624	Spring Pin	2	72		106726	Magazine Kit Assembly	(1)
23		105468	Seal, End Cap	1	48		105622	Spring	1	73		105477	Trigger Unit (ST)	(1)
24		105466	End Cap	1	49		106201	Bushing	1	74		106727	O-Ring Kit	(1)
25		105113	Hex.Soc.Hd.Bolt M4*18	3	50		105615	Toggle, Magazine	1					

